



+BAT/KL30 Battery positive terminal
-BAT Battery negative terminal
+12V Sanctioned 12V (0-30V)
+6V Buck 6V
+5V Digital 5V
+5VA Analog 5V
+5VS1 Resistive sensors 5V
+5VS2 Other sensors 5V
+5V_TPS Throttle position sensor 5V
+5V_CAN CAN transceiver 5V
+3.3V Digital 3.3V
VDDA Analog 3.3V
VREF+ Reference 3.3V
IGN/KL15 Ignition switch
HOLD Power supply hold

